




J SCHATZ EGG BIRD HOUSES.®

User Guide



INTRODUCTION

Your new Egg Bird House is easy to use. Please use this User Guide to:

Assemble and hang the Egg Bird House

Disassemble and clean out the Egg Bird House

EGG BIRD HOUSE PARTS

Your Egg Bird House consists of 5 individual Parts.


1 Stoneware Egg with Vinyl Coated Hanging Wire sealed at the Egg Bird House entry with a Rubber Grommet and Washer

1 Aluminum Perch sealed with a Clear Nylon Hole Protector

1 Aluminum Bottom with Four Ventilation/Drainage Holes

1 Aluminum Pole


1 Hitch Pin



EGG BIRD HOUSE ASSEMBLY INSTRUCTIONS

STEP 1

Turn the egg upside down.




EGG BIRD HOUSE ASSEMBLY INSTRUCTIONS


STEP 2

Position the aluminum bottom upside down in the center of the egg and insert the aluminum pole through one of the ventilation/drainage holes in the aluminum bottom. Slide the pole through the hole until parallel with the aluminum bottom and then slide it back into the opposite hole and center the pole between the holes in the aluminum bottom.


INSERT



ALIGN PARALLEL



CENTER




EGG BIRD HOUSE ASSEMBLY INSTRUCTIONS

STEP 3

Center the hole in the aluminum pole with the hole in the top of the aluminum bottom and insert the hitch pin through the pole hole and into the hole in the top of the aluminum bottom to secure the aluminum bottom in place.


Turn the Egg Bird House over and hang.



EGG BIRD HOUSE DISASSEMBLY INSTRUCTIONS

STEP 1


Turn the egg upside down and remove the hitch pin.



EGG BIRD HOUSE DISASSEMBLY INSTRUCTIONS

STEP 2


Remove the aluminum pole from the aluminum bottom. Slide the pole to the left or right until it clears the opposite hole and then slide outward at an angle.



EGG BIRD HOUSE DISASSEMBLY INSTRUCTIONS


STEP 3

Remove the base to clean out the Egg Bird House and follow the Assembly Instructions to hang.



EGG BIRD HOUSE HANGING GUIDE

Hang the Egg Bird House 3' from surrounding surfaces to prevent animals from disturbing the house. Most animals will not be able to jump onto the slippery surface of the Egg Bird House if hung at least 3' from surrounding surfaces. The Egg Bird House hanging wire is 24" and will need to be connected to an additional length of wire to hang 3' from surrounding surfaces. We recommend using a snap hook to attach the Egg Bird House to the additional length of wire. A snap hook allows the Egg Bird House to easily be removed for cleaning. Snap hooks can be found in most hardware stores.



Wonder-Certified™

Your J Schatz product is Wonder-Certified. All J Schatz products are incorporated into Jim's daily life and subjected to the wonder test to become a wonder-certified J Schatz product. The wonder test is quite simple. If a product inspires wonder throughout the weeks, months and years that Jim lives with it, the product will be produced.

About J Schatz

We at J Schatz are dreamers and explorers. Working from our studio in upstate New York, Jim and the team take inspired ideas and create ceramic ware that is pierced, scratched, carved, drilled, glazed and fired into beautifully finished products. All products are created to fit in harmony with the environment. We employ local artists, use energy-saving production methods, and our packaging contains 80% recycled content. Each product leaves our studio beautifully finished, complete with a 100% satisfaction guarantee. Indulge in a moment of wonder with a J Schatz product today.

CUSTOMER SERVICE CALL 866-344-5267

Weekdays 9a.m. - 5p.m. EST

EMAIL CUSTOMERSERVICE@JSCHATZ.COM

OR VISIT WWW.JSCHATZ.COM

Like us on Facebook: www.facebook.com/pages/J-Schatz/75559302135

Egg Bird Houses, Wonder-Certified, and J Schatz are trademarks of The Office Of Jim Schatz, Inc.
Egg Bird Houses are U.S. Patent Pending. ©2011 J Schatz. All Rights Reserved.